



DJ PROMIXER



MIDI IMPLEMENTATION



**AUDIOPHONY DJAZZ PRO
AUDIO & MIDI IMPLEMENTATION**



Installing your device Your System must to recognize your Audiophony DJ Jazz Pro as Audio Device and MIDI Device before configure in DJ ProMixer.

CONFIGURE YOUR AUDIO AND MIDI SETTINGS

IMPORTANT: Install the drivers provided for the manufacturer and check the configuration of [this equivalent controller](#).

MIDI MAP
(Overview)



Detail



- 1.- PLAY/ PAUSE
- 2.- CUE
- 3.- MANUAL LOOP (1.- IN 2.- OUT – EXIT – RELOOP)
- 4.- AUTOLOOP FROM ¼ TO 32 BEATS (STARTS IN 4 BEATS) "Active" move "<<", "Del" move ">>"
- 5.- CUP (Cue and Play)
- 6.- KEYLOCK (BY DEFAULT DISABLED)
- 7.- EFFECTS DIRECT BUTTONS EFX 1, EFX2, EFX3
- 8.- MEMORY CUE / LOOP (1,2,3,4)
- 9.- SAMPLES (1,2,3,4)
- 10.- FX SYNC (FROM 2/1 TO 1/8 BEATS)
- 11.- FX DRY / WET
- 12.- FX PARAMETER
- 13.- ENABLE WHEEL VINYL MODE
- 14.- TRACKLIST SCROLL
- 15.- LOAD DECK (A AND B)
- 16.- BROWSER (PLAYLIST, GROUPS, EXPLORER), OPEN CLOSE FOLDERS
- 17.- PFL
- 18.- ROTARY KNOBS OF THE MIXER (GAIN, HI, MID,BASS)
- 19.- DECK'S VOLUMEN CONTROLS AND CROSSFADER
- 20.- PITCH
- 21.- SYNC
- 22.- BEND (WHEEL)
- 23.- BEND (BUTTONS)
- 24.- SCRATCH
- 25.- BRAKE

More info about DJ ProMixer:

<http://www.djpromixer.com>

More info about mapping of Audiophony DJazz Pro

<http://wp.me/p1NvxM-i0>