



DJ PROMIXER



COMPATIBLE HARDWARE



PIONEER CDJ 400
AUDIO & MIDI IMPLEMENTATION

HOW TO SET UP?

- Single or dual mode (two or one CDJ's)
- Audio configuration

CDJ CONTROLLERS (HID)
SINGLE OR DUAL MODE



- 1.- PLAY/ PAUSE
- 2.- CUE
- 3.- SEARCH CUE / LOOP POINT
- 4.- MANUAL LOOP (IN – OUT – EXIT / RELOOP)
- 5.- AUTOLOOP FROM ¼ TO 32 BEATS (STARTS IN 4 BEATS)
- 6.- LINK TO PC
- 7.- SCROLL / LOAD / ENTER
- 8.- REVERSE
- 9.- SYNC
- 10.- CHANGE TEMPO RANGE
- 11.- KEYLOCK
- 12.- PITCH
- 13.- BEND
- 14.- SCRATCH (WHEEL)
- 15.- CUE / SAMPLES / EFFECTS / LOOPS SELECTOR
- 16.- CUE / SAMPLES / EFFECTS / LOOPS DIRECT BUTTONS
- 17.- CHANGE FOCUS THREE / TRACKLIST
- 18.- CHANGE FOCUS PLAYLIST / GROUPS-SUBGROUPS / EXPLORER
- 19.- CHANGE DECK (ONLY IN DUAL MODE)

IMPORTANT: TO CONNECT 2 PIONEER CDJ-400 YOU NEED A HIGH SPEED CPU

More info about DJ ProMixer:

<http://www.djpromixer.com>